



# Stop Tail Model - Dimensions

If we have asked you to measure your guitar, please measure all areas indicated by the red text.



## Correct Bridge to Stop-Tail Dimensions



Measure the top "E" saddle point to centre of stop tail post as indicated

Measure this by firstly placing a straight edge across the screw heads on the stop tail centres. Then measure from the straight edge directly to the saddle point.

Don't measure on an angle from the saddle to the screw on that side - it must be straight with the strings.

Tip - alternately try measuring from the nut to the center of the bushings and then subtract the scale length. Measuring from the bridge is often awkward as it is at a 3 degree angle with staggered saddles

## Baseplate Layout

All dimensions on this drawing in inches

